

## Tasks

### Tanks:

- Do not stand in path of swing
- Do not stand between tanks while swinging
- Wait for tank to be set on ground and operator to give OK before approaching
- If leveling is required:
  - Use tools only under tank
  - Do not put any body parts under tank
- Do not try to push tank to accelerate movement
- Allow crane to position load
- If using spacer between tanks:
  - Do not put any body part between spacer and tank

### Catwalks and stairs:

- Stay clear while standing vertical
- Use tag line
- Do not stand in path of swing
- Do not cross under
- Do not put fingers between catwalk/stairs and mounting brackets

### Separators:

- Do not stand in path of swing
- Do not cross under
- Do not stand between separators while swinging
- Always use tag line
- Do not pull hard on tag line
- Keep body parts out from under
- Stay back till operator gives the OK to approach
- Use tools (never body parts) to level if needed
- Keep fingers clear when setting burner stack

### Concrete tanks:

- Do not stand in path of swing
- Do not cross under
- Stay out of hole till concrete tank is on bottom
- Avoid standing between concrete tank and walls (especially if above 4' high)
- Be cautious of wall closest to the crane (most likely to collapse)
- Do not be inside tank while being lifted
- Do not put body parts under tank
- Do not put fingers between tank and lid
- Outrigger distance must be a minimum of depth of hole or at 30 degree to bottom in loose soil conditions

### Flare Units:

- Do not stand in path of swing
- Do not cross under
- Keep fingers out from between burner and stack
- Using a hole alignment tool: keep fingers out from

- between tool and burner
- Use tools for leveling

### Treaters:

- Stay clear while standing vertical
- Use tag line
- Do not stand in path of swing
- Do not cross under
- Use tools (never body parts) to level if needed
- Do not stand between treater and solid object while in motion

### Sand traps:

- Stay clear while standing vertical
- Use tag line
- Do not stand in path of swing
- Do not cross under
- Use tools (never body parts) to level if needed
- Do not stand between treater and solid object while in motion

### VOC Overhead Pipe:

- Use tag line
- Do not stand in path of swing
- Do not cross under
- Keep hands and fingers away from pipe end
- Allow crane to position load

## Tasks